

Log Erosion Barriers (LEBs)

Denver Federal Center Building 56, Room 2604 PO Box 25426 Denver, Co 80225-0426

720-544-2810 - office *www.co.nrcs.usda.gov*



What are log erosion barriers?

Log Erosion Barriers (LEBs) are logs placed in a shallow trench on the contour to intercept water running down a slope and trap sediment. This treatment may also be known as contour log felling, log terraces or terracettes.

When are log erosion barriers used?

Log erosion barriers are used on moderate or severely burned slopes ranging between 20% to 60%, with erosive soils. LEBs are used where erosion rates have increased significantly because of the fire and there are high values at risk downstream. The site must have enough trees of adequate size to meet treatment objectives (at least 60 trees per acre). Soils can be shallow, but not less than about 8 inches. LEBs increase infiltration, adds roughness, reduce erosion, and help retain small amounts of eroded soil on site. LEBs should be effective for a period of one to two years, providing short term protection on slopes where permanent vegetation will re-establish and provides long term erosion control.

What materials are needed?

- 6-12 inch diameter logs, 10-30 feet long
- An expert sawyer and labor crew with hand tools
- Machines may be used for moving logs or trenching them in on 30% or flatter slopes

How are log erosion barriers installed?

A contour line is marked on the slope to identify the approximate cross slope alignment. Trees along this line are felled on the upstream side of the contour line as much as possible. Stumps are left about 12" high to brace the tree. The logs are cut to a length that permits safe handling and placement for the crew, generally 10 to 30 feet. Tree limbs are removed to the extent necessary for the log to lie flat on the ground. A shallow trench (about 4 to 6 inches deep) is dug along the contour. The log is placed in the trench and seated with tamped backfill such that water flowing down the slope will not run under it. For this practice to be effective, enough trees must be felled along the contour line to create a semi continuous barrier to the movement of water down the slope, as shown in Figure 1 & 2.

How many log erosion barriers are required?

Depending on characteristics of the slope, somewhere between 60 and 152 trees per acre are needed for use of LEBs to be effective. Figure 1 depicts the pattern of LEBs on the slope, and Table 1 shows recommended spacing.




FIGURE 1 - Theoretical log terracing pattern




FIGURE 1 - Typical log & bedding detail

Slope steepness (percent)	Burn Intensity	
	Moderate	Severe
	Spacing (feet)	
10 - 20%	60	40
20 - 50 %	30	20
> 50%	15	10

TABLE - Recommended spacing for contour slope treatments

NOTE: After a fire many trees are weakened from burning around the base of the trunk. The trees can fall over or blow down without warning. Shallow rooted trees can also fall. Therefore be extremely alert when around burned trees.